

4766-5-16

Temporary use of aircraft and disaster operations.

- (A) No AMSO shall operate an aircraft without a permit issued in accordance with section 4766.07 of the Revised Code, a temporary permit issued in accordance with this section, or in the event of a disaster situation.
- (B) An AMSO may obtain a temporary permit by submitting an executed temporary aircraft permit affidavit on a form prescribed by the board. The temporary aircraft permit affidavit shall include assertions that the AMSO shall:
- (1) Use the temporary permit for the sole purpose of temporarily replacing the specific primary aircraft that is out-of-service;
 - (2) Clearly and conspicuously display the temporary permit on any temporary aircraft used by the AMSO;
 - (3) Immediately remove the temporary permit from the temporary aircraft upon the return to service of the primary aircraft;
 - (4) Ensure that any temporary aircraft used by the AMSO will be equipped in accordance with the requirements of rule 4766-5-22 of the Administrative Code.
 - (5) Not use the temporary permit for any purpose when the primary aircraft is in service.
- (C) The AMSO shall complete and maintain a log for the temporary permit at any time the temporary permit is used by or removed from a temporary aircraft.
- (D) The board shall create a temporary aircraft permit which shall contain a log form to be completed by the AMSO at any time the temporary permit is used by or removed from a temporary aircraft.
- (E) An AMSO shall ensure that:
- (1) A temporary permit is used only to replace the specific primary aircraft that is out-of-service;
 - (2) The temporary permit is conspicuously displayed on the temporary aircraft used by the AMSO;
 - (3) Upon return to service of any primary aircraft, the temporary permit used on a

temporary aircraft must be removed immediately;

- (4) Any temporary permit not in use shall be stored and made readily available to the board upon request;
- (5) The log form on the temporary permit is completed at any time the temporary permit is used by or removed from a temporary aircraft;
- (6) No temporary permit shall be used when the specific primary aircraft is in service.

TO BE RESCINDED